Fibershield®-S





Product Description

textile fire protection curtain

Fire protection that goes around corners: The basic surface of the closure can be created as a rectangular and polygon-shape with angles between 30° and 150°. No support elements are required despite corner designs. In addition to closed polygon forms, open systems can also be realised that close against the wall using special guide rails. A spring-mounted closure strip serves to create a clean closure to the ceiling. The fire protection curtain can be closed without any external energy using a stand installed 'Gravigen' drive system. The Fibershield-S allows complex shield geometries to be realised and at the same time satisfies and the requirements of the room closure for more than 90 minutes.

construction type textile fire protection curtain

executable protection target EI - with fire load free zone • EW

90 • EI - with sprinklers

fabric Ecotex 1100 A2 • Heliotex

fire load free zone Protex/Ecotex: El 30/60/90min

100/150/200 cm • Heliotex: El 30/60/90min 20/30/50 cm **closing direction** from top to bottom

proof IBS 08062416

closing cycle C1 number of closing cycles 500


V EN-20200211 1 stoebich.com

Fibershield®-S



Constructive structure (System drawing)

Fabric	System width	Drop length	t	h
Ecotex 1100 A2	< 50 m	< 3 m	490 mm	125 mm
Ecotex 1100 A2	< 50 m	> 3 m - ≤ 6 m	490 mm	225 mm
Heliotex EW 90	< 50 m	< 2,2 m	490 mm	125 mm
Heliotex EW 90	< 50 m	> 2,2 m - ≤ 2,5 m	490 mm	225 mm
Heliotex EW 90	< 50 m	> 4,5 m - ≤ 6 m	490 mm	450 mm



 ^{1 =} Smoke detector 2 = Casing
3 = Side guids
4 = Tubular motor
5 = Fabric
6 = Closing element
7 = Coil
8 = Control module
9 = Control with operating unit
10 = Manual release
SL = System length


Fibershield®-S




bottom bar

standard

special







Fibershield®-S



housing


standard







housing

special








Fibershield®-S



side guides



Fibershield®-S



references

Segeberger clinics

